



LED TV

Chassis : U88C

Model : UN32FH4003G

UN39FH5003G

UN40FH5003G

UN46FH4003G

SERVICE Manual

LED TV



UN**FH5003G

Contents

1. Precautions
2. Product specifications
3. Disassembly and Reassembly
4. Troubleshooting
5. Wiring Diagram

Contents

1. Precautions	1-1
1-1. Safety Precautions	1-1
1-2. Servicing Precautions	1-3
1-3. Static Electricity Precautions	1-4
1-4. Installation Precautions	1-5
2. Product Specifications	2-1
2-1. Product Information	2-1
2-2. Detail Factory Option	2-8
2-3. Accessories	2-9
3. Disassembly and Reassembly	3-1
3-1. Disassembly and Reassembly	3-1
3-2. Assy Board P-Jog Switch & Ir	3-10
3-3. Disassembly(PTC)	3-12
4. Troubleshooting	4-1
4-1. Troubleshooting	4-1
4-2. How to Check Fault Symptom	4-4
4-3. Factory Mode Adjustments	4-7
4-4. White Balance	4-16
4-5. White Ratio (Balance) Adjustment	4-19
4-6. RS-232C	4-20
4-7. AV Control Table	4-22
4-8. Software Upgrade	4-28
4-9. Rear Cover Dimension	4-30
5. Wiring Diagram	5-1
5-1. Wiring Diagram	5-1
5-2. Connector	5-2
5-3. Connector Functions	5-4
5-4. Cables	5-5



**This Service Manual is a property of Samsung Electronics Co.,Ltd.
Any unauthorized use of Manual can be punished under applicable
International and/or domestic law.**

**© 2013 Samsung Electronics Co.,Ltd.
All rights reserved.
Printed in Korea**