



LED TV

Chassis : U8MC

Model : UN40H5103AG

SERVICE Manual

LED TV



UN40H5103AG

Contents

1. Precautions
2. Product specifications
3. Disassembly and Reassembly
4. Troubleshooting
5. Wiring Diagram

Contents

1. Precautions	1-1
1-1. Safety Precautions	1-1
1-1-1. Warnings.....	1-1
1-1-2. Servicing the LED TV	1-1
1-1-3. Fire and Shock Hazard	1-1
1-1-4. Product Safety Notices	1-2
1-2. Servicing Precautions.....	1-3
1-2-1. General Servicing Precautions	1-3
1-3. Static Electricity Precautions	1-4
1-4. Installation Precautions	1-5
2. Product Specifications.....	2-1
2-1. Product information	2-1
2-2. Product specification	2-2
2-2-1. Detailed Specifications	2-2
2-2-2. Feature & Specifications.....	2-7
2-3. Accessories	2-8
3. Disassembly and Reassembly	3-1
3-1. Disassembly and Reassembly	3-1
4. Troubleshooting	4-1
4-1. Troubleshooting.....	4-1
4-1-1. Testing the Picture	4-1
4-1-2. Testing the Sound	4-3
4-1-3. There is a problem with the broadcast.....	4-4
4-1-4. My computer won't connect	4-4
4-1-5. I can't connect to the Internet	4-4
4-1-6. I am having trouble launching/using apps	4-4
4-1-7. My file won't play	4-5
4-1-8. I want to reset the TV.....	4-5
4-1-9. Other Issues	4-6
4-2. Connect	4-7
4-3. Factory Mode Adjustments	4-9
4-3-1. Detail Factory Option	4-9
4-3-2. Entering Factory Mode	4-10
4-3-3. Factory Data	4-11
4-4. White Balance	4-24
4-4-1. Calibration	4-24
4-4-2. Service Adjustment.....	4-24
4-4-3. Adjustment.....	4-26

4-5. Software Upgrade.....	4-27
4-5-1. By USB	4-27
4-5-2. By Online	4-27
4-5-3. Alternative Software (Backup)	4-27
4-6. Rear Cover Dimension	4-28
4-6-1. UN40H51*3 Cover Rear Dimension	4-28
5. Wiring Diagram.....	5-1
5-1. Wiring Diagram.....	5-1
5-2. Connector	5-2
5-3. Connector Functions	5-6



**This Service Manual is a property of Samsung Electronics Co.,Ltd.
Any unauthorized use of Manual can be punished under applicable
International and/or domestic law.**

**© 2014 Samsung Electronics Co.,Ltd.
All rights reserved.
Printed in Korea**